

Measuring and Installation Instructions – Arch Tops and Transom Tops

Required for Installation:

Electric drill, 1/4" drill bit, hammer, clips, shutter fasteners. (1/4" carbide drill bit is required for stucco, hardboard, fiber cement, brick, or masonry.)

Step 1

Attach the Arch/Transom Top to the shutter by using the clips provided. Align the shutter and the Arch/Transom Top on a flat surface. Join them together by pushing each clip on as far as it will go. Use 2 clips per Arch/Transom Top as shown below.

Step 2

Drill holes in shutter and wall as shown in the instructions on pages 4-5.

Step 3

Also, drill 1/4" hole into the Arch/Transom Top and 2 1/2" into the wall as shown below.

Step 4

Grasp the shutter fastener by supporting the shank, and push it through the shutter hole and into the wall surface. Tap the shutter fastener gently with a hammer to snug the shutter and Arch/Transom Top against the siding. Do not over tighten, or this will cause the shutter to dimple.

